

TAKE DOWN

1. **Crossbar and Net!** Lift the crossbar off the top of the upper side poles, and lower it and the attached net into the channel. Stuff the net into the channel and the **shove the net rings down below pivot point at the bottom of the lower side poles**. Push the crossbar down on the net, and position the crossbar **diagonally** in the channel.
2. **Upper Side Poles and Lower Sides Poles!** Remove the upper side poles. Swing the lower side poles flat into the channel. Next lay the upper side poles flat in the channel.
3. **Legs!** Tilt the channel on end, and fold the legs under it. Do both legs on the one side beginning with the leg that has the small dot on the top of it. Then do both legs on the other side, also beginning with the dotted leg.

Now You're Ready to Travel! Be sure to keep the shoulder strap firmly on your shoulder and watch out for others when carrying it.

5. **Buckles!** You will not need the buckles for everyday use so long as you keep the channel upright when transporting your Pitch Safe™ Pitching Screen. For airline check-in and extra security while traveling with your Pitching Screen, wrap the snap buckle straps completely around the channel and the legs about 8 inches from each end. Check to make sure that the straps are tight, that the snap buckles are fully clasped, and that all parts are contained within the channel.